

## A320 NORMAL CHECKLIST

### DEPARTURE

### ARRIVAL

BEFORE START	
COCKPIT PREP .....	COMPLET(BOTH)
PINS AND COVERS .....	REMOVED
SIGNS .....	ON/AUTO
ADIRS .....	NAV
FUEL QUANTITY .....	___KG
TO DATA/V.BUGS .....	___SET (BOTH)
BARO REF .....	___SET (BOTH)
-----	
MOBILE PHONES .....	OFF
A/SKID & N/W STEERING.....	AS RQRD
WINDOWS/DOORS .....	CLOSED (BOTH)
BEACON .....	ON/AUTO
THR LEVERS .....	IDLE
PARKING BRAKE .....	AS RQRD

- |                             |           |
|-----------------------------|-----------|
| 1) Eng Mstr Swtch           | OFF       |
| 2) Eng Start Selector       | NORM      |
| 3) ENG Man Start PB         | OFF       |
| 4) Check ECAM oil 10 qts ++ | <=====    |
| 5) Eng Start Selector       | IGN/Start |
| 6) Eng 1 Mstr Swtch         | ON        |
| wait 30 sec                 |           |
| 7) Eng 2 Mstr Swtch         | ON        |
| wait 30 sec                 |           |

AFTER START	
ANTI-ICE .....	AS RQRD
ECAM STATUS .....	CHECKED
APU .....	AS RQRD
PITCH TRIM .....	___SET
RUDDER TRIM .....	ZERO
GROUND CREW .....	CLEAR
A/SKID & N/W STEERING.....	ON

- |                       |      |        |
|-----------------------|------|--------|
| 1) Eng Start Selector | NORM | <===== |
|-----------------------|------|--------|

BEFORE TAKEOFF	
FLIGHT CONTROLS .....	CHECKED (BOTH)
FLT INST .....	CHECKED (BOTH)
BRIEFING .....	CONFIRMING
FLAP SETTING .....	CONF ___(BOTH)
V1. VR. V1/FLEX TEMP.....	___(BOTH)
BUMP/DE-RATE .....	AS RQRD
ATC+TCAS .....	SET
RADAR + PWS .....	SECURED FOR TO
CABIN .....	TO NO BLUE
ECAM MEMO .....	
<ul style="list-style-type: none"> <li>• AUTO BRK MAX</li> <li>• SIGNS ON</li> <li>• SPLRS ARM</li> <li>• FLAPS TO</li> <li>• TO CONFIG NORM</li> </ul>	
LAPTOP .....	STOWED
-----	
STROBELIGHTS .....	AS RQRD
CABIN CREW .....	ADVISED
ENG MODE SEL .....	AS RQRD
PACKS .....	AS RQRD

AFTER TAKEOFF/CLIMB	
LDG GEAR .....	UP
FLAPS .....	ZERO
PACKS .....	ON
-----	
BARO REF .....	___SET (BOTH)

APPROACH	
BRIEFINGS .....	CONFIRMED
ECAM STATUS .....	CHECKED
V.BUGS .....	SET (BOTH)
SEAT BELTS .....	ON
BARO / MDA /DH .....	___SET (BOTH)
ENG MODE SEL .....	AS RQRD
AUTOBRAKE .....	AS RQRD

LANDING	
CABIN CREW .....	SECURED AND ADVISED
A/THR .....	SPEED/OFF
GO AROUND ALT .....	___SET
ECAM MEMO .....	LDG NO BLUE
L/G DOWN	
SIGNS ON	
SPLRS ARM	
FLAPS SET	

AFTER LANDING	
Consider Adverse Weather	
FLAPS .....	RETRACTED
SPOILERS .....	DISARMED
APU .....	START
RADAR/TCAS/PWS.....	OFF/STBY
STROBE LIGHTS .....	AUTO

PARKING	
APU BLEED .....	ON
ENGINES .....	OFF
SEAT BELTS .....	OFF
EXT LT .....	AS RQRD
FUEL PUMPS .....	OFF
PARK BRK AND CHOCKS .....	AS RQRD
CAPT'S MOBILE PHONE .....	ON

SECURING THE AIRCRAFT	
ADIRS .....	OFF
OXYGEN .....	OFF
APU BLEED .....	OFF
EMER EXIT LT .....	OFF
NO SMOKING .....	OFF
APU AND BAT .....	OFF
LAPTOP .....	SECURED